INSTRUCTIONS:

1. Remove the switch plate, outlet cover, or wall element.
2. Wipe clean the area around the damaged area removing dust, while pushing in any protruding drywall.
3. For single goof patch repairs: peel off the goof patch from the backing and apply it to the wall around the outlet. Be sure to apply the patch just above the metal hold down tabs on the outlet or switch. This will allow the removal of the outlet or switch at another time without affecting the goof patch.
4. You can either paint at this time, or for a perfect match to the surrounding wall surface you can either skim the edges with joint compound, or texture.
5. Replace the switch cover after the paint has dried to complete the job.
6. For double switch or outlet covers follow numbers 1 & 2 above and precede below.
7. You will need two goof patches to make the repair. First you will need to cut the end off of both of the goof patches (refer to the package images).
8. Remove the backing from one of the cut goof patches, and apply it to one side of the switch or outlet needed the repair. Be sure to apply it above the metal hold down tabs.
9. Remove the backing from the other cut goof patch and apply it to the other end of the repair area.
10. You can either paint at this time, or for a perfect match to the surrounding wall surface you can either skim the edges with joint compound, or texture.
11. Replace the switch cover after the paint has dried to complete the job.
12. You can view a demonstration video on our web site at www.GoofPatch.com, or at www.DuraGuardProducts.com

LAS INSTRUCCIONES:

1. Retire la placa de cambio, cubrir la salida, o elemento de pared.
2. Limpie el área alrededor de la zona dañada, en la eliminación de polvo, mientras que pulsando en cualquier protuberantes drywall.
3. Para un solo parche repara goof: desprenderse de la revisión de goof el respaldo y aplicarlo a la pared alrededor de la toma de corriente. Asegúrese de aplicar el parche justo por encima del metal mantenga pulsada fichas sobre la toma de corriente o interruptor. Esto permitirá la eliminación de la toma de corriente o cambiar en otro momento sin afectar a la goof parche.
4. Puede pintar en este momento, o para un ajuste perfecto a la que rodea la superficie de la pared puede pasar rozando los bordes con el conjunto compuesto, o la textura.
5. Reemplace el interruptor cubrir después de la pintura se ha secado para completar el trabajo.
6. Para cambiar o doble salida cubre las números 1 y 2 por encima y por debajo de preceder.
7. Usted necesitará goof dos parches para hacer la reparación. En primer lugar tendrá que cortar el final fuera de los dos parches goof (consulte el paquete de imágenes).
8. Retire el respaldo de uno de los cortados goof parches, y aplicarlo a un lado del interruptor de salida o la reparación necesaria. Asegúrese de aplicarlo sobre el metal mantenga pulsada pestañas.
9. Retire el respaldo de la otra corte goof parche y aplicarlo en el otro extremo de la reparación de la zona.
10. Puede pintar en este momento, o para un ajuste perfecto a la que rodea la superficie de la pared puede pasar rozando los bordes con el conjunto compuesto, o la textura.
11. Reemplace el interruptor cubrir después de la pintura se ha secado para completar el trabajo.
12. Puede ver una demostración en vídeo en nuestra página web en www.GoofPatch.com, o al www.DuraGuardProducts.com